

Geothermal Heat Pumps Product List
List Current as of March 18, 2009

Organization Name	Model Name	Product Type	Model Number
Advanced Geothermal Technology		DX with integrated WH	All Models beginning with GC
Bard Manufacturing Company, Inc.	GeoTec	Closed Loop with integrated WH	Any model starting with GV in sizes 27 to 71
Bard Manufacturing Company, Inc.	GeoTec	Open Loop with integrated WH	Any model starting with GV in sizes 27 to 71
Bard Manufacturing Company, Inc.	GSVS Series	Closed Loop with integrated WH	Any model starting with GSVS in sizes 242-601
Bard Manufacturing Company, Inc.	GSVS Series	Open Loop with integrated WH	Any model starting with GSVS in sizes 242-601
Bard Manufacturing Company, Inc.	Q-Tec	Closed Loop with integrated WH	Any model starting with QW in sizes 30-42
Bard Manufacturing Company, Inc.	Q-Tec	Open Loop with integrated WH	Any model starting with QW in sizes 24-48
Bryant (Carrier Corporation)	GT-G	Closed Loop	Any model starting with 50YC (V/H/D) in sizes 015 to 060
Bryant (Carrier Corporation)	GT-G	Open Loop	Any model starting with 50YC (V/H/D) in sizes 015 to 070
Bryant (Carrier Corporation)	GT-GS	Closed Loop	Any model starting with 50YCS in sizes 018 to 060
Bryant (Carrier Corporation)	GT-GS	Open Loop	Any model starting with 50YCS in sizes 018 to 060
Bryant (Carrier Corporation)	GT-PG	Closed Loop	Any model starting with 50YE in sizes 018 to 070
Bryant (Carrier Corporation)	GT-PG	Open Loop	Any model starting with 50YE in sizes 018 to 070
Bryant (Carrier Corporation)	GT-PX	Closed Loop	Any model starting with 50YD in sizes 026 to 072
Bryant (Carrier Corporation)	GT-PX	Open Loop	Any model starting with 50YD in sizes 026 to 072
Bryant (Carrier Corporation)	GT-S	Closed Loop	Any model starting with 38WQS in sizes 018 to 060
Bryant (Carrier Corporation)	GT-S	Open Loop	Any model starting with 38WQS in sizes 018 to 060
Carrier Corporation	50vs Series	Closed Loop	VHC1
Carrier Corporation	50vs Series	Closed Loop	VHC2
Carrier Corporation	50vs Series	Closed Loop	VHC3
Carrier Corporation	50vs Series	Closed Loop	VHC4
Carrier Corporation	50vs Series	Closed Loop	VHC5
Carrier Corporation	50vs Series	Closed Loop	VHC6
Carrier Corporation	50vs Series	Closed Loop	VHC7
Carrier Corporation	50vs Series	Open Loop	VHC1
Carrier Corporation	50vs Series	Open Loop	VHC2
Carrier Corporation	50vs Series	Open Loop	VHC3
Carrier Corporation	50vs Series	Open Loop	VHC4
Carrier Corporation	50vs Series	Open Loop	VHC5
Carrier Corporation	50vs Series	Open Loop	VHC6
Carrier Corporation	50vs Series	Open Loop	VHC7
Carrier Corporation	AQUAZONE	Closed Loop	Any model starting with 50PS in sizes 018 to 060, with ECM blower

Organization Name	Model Name	Product Type	Model Number
Carrier Corporation	AQUAZONE	Closed Loop	Any model starting with 50PT in sizes 026 to 064
Carrier Corporation	AQUAZONE	Closed Loop	Any model starting with 50R(V/D/H)S in sizes 015 to 060
Carrier Corporation	AQUAZONE	Open Loop	Any model starting with 50PS in sizes 018 to 060, with ECM blower
Carrier Corporation	AQUAZONE	Open Loop	Any model starting with 50PS in sizes 018 to 070, with ECM blower
Carrier Corporation	AQUAZONE	Open Loop	Any model starting with 50PT in sizes 026 to 064
Carrier Corporation	AQUAZONE	Open Loop	Any model starting with 50R(V/D/H)S in sizes 015 to 070
Carrier Corporation	GT-G	Closed Loop	Any model starting with 50YC(V/H/D) in sizes 015 to 060
Carrier Corporation	GT-G	Open Loop	Any model starting with 50YC(V/H/D) in sizes 015 to 070
Carrier Corporation	GT-GS	Closed Loop	Any model starting with 50YCS in sizes 018 to 060
Carrier Corporation	GT-GS	Open Loop	Any model starting with 50YCS in sizes 018 to 060
Carrier Corporation	GT-PG	Closed Loop	Any model starting with 50YE in sizes 018to 070
Carrier Corporation	GT-PG	Open Loop	Any model starting with 50YE in sizes 018 to 070
Carrier Corporation	GT-PX	Closed Loop	Any model starting with 50YD in sizes 026 to 072
Carrier Corporation	GT-PX	Open Loop	Any model starting with 50YD in sizes 026 to 072
Carrier Corporation	GT-S	Closed Loop	Any model starting with 38WQS in sizes 018 to 060
Carrier Corporation	GT-S	Open Loop	Any model starting with 38WQS in sizes 018 to 060
Eagle Mountain	Denali	Closed Loop	GMVXVO15
Eagle Mountain	Denali	Closed Loop	GMVXVO18
Eagle Mountain	Denali	Open Loop	GMVXVO15
Eagle Mountain	Denali	Open Loop	GMVXVO18
Eagle Mountain	Everest	Closed Loop	GMGS22
Eagle Mountain	Everest	Closed Loop	GMGS30
Eagle Mountain	Everest	Closed Loop	GMGS36
Eagle Mountain	Everest	Closed Loop	GMGS42
Eagle Mountain	Everest	Closed Loop	GMGS48
Eagle Mountain	Everest	Closed Loop	GMGS60
Eagle Mountain	Everest	Closed Loop	GMGS70
Eagle Mountain	Everest	Closed Loop	GMGT26
Eagle Mountain	Everest	Closed Loop	GMGT38
Eagle Mountain	Everest	Closed Loop	GMGT49
Eagle Mountain	Everest	Closed Loop	GMGT64
Eagle Mountain	Everest	Closed Loop	GMGT72
Eagle Mountain	Everest	Open Loop	GMGS22
Eagle Mountain	Everest	Open Loop	GMGS30
Eagle Mountain	Everest	Open Loop	GMGS36

Organization Name	Model Name	Product Type	Model Number
Eagle Mountain	Everest	Open Loop	GMGS42
Eagle Mountain	Everest	Open Loop	GMGS48
Eagle Mountain	Everest	Open Loop	GMGS60
Eagle Mountain	Everest	Open Loop	GMGS70
Eagle Mountain	Everest	Open Loop	GMGT26
Eagle Mountain	Everest	Open Loop	GMGT38
Eagle Mountain	Everest	Open Loop	GMGT49
Eagle Mountain	Everest	Open Loop	GMGT64
Eagle Mountain	Everest	Open Loop	GMGT72
Eagle Mountain	Rainier	Closed Loop	GMQT38
Eagle Mountain	Rainier	Closed Loop	GMQT49
Eagle Mountain	Rainier	Closed Loop	GMQT64
Eagle Mountain	Rainier	Closed Loop	GMQT72
Eagle Mountain	Rainier	Open Loop	GMQT38
Eagle Mountain	Rainier	Open Loop	GMQT49
Eagle Mountain	Rainier	Open Loop	GMQT64
Eagle Mountain	Rainier	Open Loop	GMQT72
Eagle Mountain	Sierra	Closed Loop	GMPO10
Eagle Mountain	Sierra	Closed Loop	GMPO13
Eagle Mountain	Sierra	Closed Loop	GMPO19
Eagle Mountain	Sierra	Closed Loop	GMPO22
Eagle Mountain	Sierra	Closed Loop	GMPO28
Eagle Mountain	Sierra	Closed Loop	GMPO34
Eagle Mountain	Sierra	Closed Loop	GMPO40
Eagle Mountain	Sierra	Closed Loop	GMPO46
Eagle Mountain	Sierra	Closed Loop	GMPO56
Eagle Mountain	Sierra	Closed Loop	GMPO66
Eagle Mountain	Sierra	Open Loop	GMPO22
Eagle Mountain	Sierra	Open Loop	GMPO40
EarthLinked Technologies	EarthlinkedTM	DX	All models beginning with HC
EarthLinked Technologies	EarthlinkedTM	DX	All models beginning with HW
EarthLinked Technologies	EarthlinkedTM	DX	All models beginning with SC
EarthLinked Technologies	EarthlinkedTM	DX	SC-024-1
EarthLinked Technologies	EarthlinkedTM	DX	SC-030-1
EarthLinked Technologies	EarthlinkedTM	DX	SC-036-1
EarthLinked Technologies	EarthlinkedTM	DX	SC-042-1

Organization Name	Model Name	Product Type	Model Number
EarthLinked Technologies	EarthlinkedTM	DX	SC-048-1
EarthLinked Technologies	EarthlinkedTM	DX	SC-060-1
EarthLinked Technologies	EarthlinkedTM	DX	SC Series
EarthLinked Technologies	EarthlinkedTM	DX	SW Series
EarthLinked Technologies	EarthlinkedTM	DX with integrated WH	All models beginning with CWH
EarthLinked Technologies	EarthlinkedTM	DX with integrated WH	All models beginning with HCW
EarthLinked Technologies	EarthlinkedTM	DX with integrated WH	All models beginning with HWW
EarthLinked Technologies	EarthlinkedTM	DX with integrated WH	All models beginning with SCW
EarthLinked Technologies	EarthlinkedTM	DX with integrated WH	All models beginning with SD
EarthLinked Technologies	EarthlinkedTM	DX with integrated WH	All models beginning with SW
EarthLinked Technologies	EarthlinkedTM	DX with integrated WH	All models beginning with SWW
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GH181
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GH231
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GH291
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GV181
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GV231
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GV291
ECONAR GeoSystems, LLC.	GeoSource 2000	Closed Loop	Any Model Starting with GV361
ECONAR GeoSystems, LLC.	GeoSource 2000	Open Loop	All Models Starting with GH231
ECONAR GeoSystems, LLC.	GeoSource 2000	Open Loop	All Models Starting with GV231
ECONAR GeoSystems, LLC.	GeoSource 2000	Open Loop	All Models Starting with GV361
ECONAR GeoSystems, LLC.	GeoSource DualTEK	Closed Loop	Any Model Starting with GV361
ECONAR GeoSystems, LLC.	GeoSource DualTEK	Open Loop	All Models Starting with GV361
ECONAR GeoSystems, LLC.	GeoSource Vara	Closed Loop	Any Model Starting with GV361
ECONAR GeoSystems, LLC.	GeoSource Vara	Open Loop	All Models Starting with GV361
ECONAR GeoSystems, LLC.	Invision3	Closed Loop	Any Model Starting with Q14kW4T
ECONAR GeoSystems, LLC.	Invision3	Closed Loop	Any Model Starting with Q16kW6T
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any models starting with GV471
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any models starting with GV571
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any models starting with GV771
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any model starting with GH371
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any model starting with GH571
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any model starting with GH781
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any model starting with GV371
ECONAR GeoSystems, LLC.	Ultra Forced Air	Closed Loop	Any model starting with GV781
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any models starting with GV471

Organization Name	Model Name	Product Type	Model Number
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any models starting with GV571
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any models starting with GV771
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any model starting with GH371
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any model starting with GH571
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any model starting with GH781
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any model starting with GV371
ECONAR GeoSystems, LLC.	Ultra Forced Air	Open Loop	Any model starting with GV781
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GH381
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GH481
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GH581
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GV381
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GV481
ECONAR GeoSystems, LLC.	Vara2Plus	Closed Loop	Any Model Starting with GV581
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GH381
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GH481
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GH581
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GV381
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GV481
ECONAR GeoSystems, LLC.	Vara2Plus	Open Loop	All Models Starting with GV581
FHP Manufacturing	Aquarius	Closed Loop	All AU Series Models CF, HZ, VT, CS
FHP Manufacturing	Aquarius	Closed Loop	CA Series Models 009, 012, 015
FHP Manufacturing	Aquarius	Closed Loop	EC Series Models CF, HZ, VT, 015, 018, 024
FHP Manufacturing	Aquarius	Closed Loop	EC Series Models CF, HZ, VT, 030, 036, 042, 048, 051, 060, 061, 070
FHP Manufacturing	Aquarius	Closed Loop	EC Series Models CS 018, 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing	Aquarius	Open Loop	All AU Series Models CF, HZ, VT, CS
FHP Manufacturing	Aquarius	Open Loop	CA Series Models 009, 012, 015
FHP Manufacturing	Aquarius	Open Loop	EC Series Models CF, HZ, VT, 007, 009, 012, 015, 018, 024
FHP Manufacturing	Aquarius	Open Loop	EC Series Models CF, HZ, VT, 030, 036, 042, 048, 051, 060, 061, 070
FHP Manufacturing	Aquarius	Open Loop	EC Series Models CS 018, 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing	Aquarius 2	Closed Loop	All AP Series Models CF, HZ, VT
FHP Manufacturing	Aquarius 2	Open Loop	All AP Series Models CF, HZ, VT
FHP Manufacturing	Energy Miser	Closed Loop	EM Series Models CF, HZ, VT, 024, 028, 036, 051, 061

Organization Name	Model Name	Product Type	Model Number
FHP Manufacturing	Energy Miser	Open Loop	EM Series Models CF, HZ, VT, 007, 009, 018, 024, 028
FHP Manufacturing	Energy Miser	Open Loop	EM Series Models CF, HZ, VT, 031, 036, 041, 042, 048, 051, 060, 061, 070
FHP Manufacturing	EnviroMiser	Closed Loop	ALL EV Series Models CF, HZ, VT
FHP Manufacturing	EnviroMiser	Closed Loop	EV Series Models CS 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing	EnviroMiser	Open Loop	ALL EV Series Models CF, HZ, VT
FHP Manufacturing	EnviroMiser	Open Loop	EV Series Models CS 024, 030, 036, 042, 048, 060, 070
FHP Manufacturing	EnviroSaver	Closed Loop	ALL ES Series Models CF, HZ, VT
FHP Manufacturing	EnviroSaver	Closed Loop	ES Series Models CS 018, 024, 025, 030, 035, 036
FHP Manufacturing	EnviroSaver	Closed Loop	ES Series Models CS 042, 048, 049, 060, 061, 070, 071
FHP Manufacturing	EnviroSaver	Open Loop	ALL ES Series Models CF, HZ, VT
FHP Manufacturing	EnviroSaver	Open Loop	ES Series Models CS 018, 024, 025, 030, 035, 036
FHP Manufacturing	EnviroSaver	Open Loop	ES Series Models CS 042, 048, 049, 060, 061, 070, 071
FHP Manufacturing	Geo Saver	Closed Loop	All GS Series Models CF, HZ, VT
FHP Manufacturing	Geo Saver	Open Loop	All GS Series Models CF, HZ, VT
FHP Manufacturing	Geo Thermal	Closed Loop	All GT Series Models CF, HZ, VT
FHP Manufacturing	Geo Thermal	Open Loop	All GT Series Models CF, HZ, VT
GeoMaster, LLC	GeoExcel	Closed Loop	All AU Models VT, HZ, CF, CS
GeoMaster, LLC	GeoExcel	Closed Loop	All ES Models VT, HZ, CF, CS
GeoMaster, LLC	GeoExcel	Closed Loop	All EV Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	Closed Loop	All GS Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	Closed Loop	All GT Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	Closed Loop	CA009, 012, 015
GeoMaster, LLC	GeoExcel	Closed Loop	EC Models CS 018, 024, 030, 036, 042, 048, 060, 070
GeoMaster, LLC	GeoExcel	Closed Loop	EC Models VT, HZ, CF 015, 018, 024, 030, 036, 042, 048, 051, 060, 061, 070
GeoMaster, LLC	GeoExcel	Closed Loop	EM Models VT, HZ, CF 024, 028, 036, 051, 061
GeoMaster, LLC	GeoExcel	Closed Loop	EV Models CS 024, 030, 036, 042, 048, 060, 070
GeoMaster, LLC	GeoExcel	Closed Loop	GT010,018,024,030,036,042,048,054
GeoMaster, LLC	GeoExcel	Open Loop	All AU Models VT, HZ, CF, CS
GeoMaster, LLC	GeoExcel	Open Loop	All ES Models VT, HZ, CF, CS
GeoMaster, LLC	GeoExcel	Open Loop	All EV Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	Open Loop	All GS Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	Open Loop	All GT Models VT, HZ, CF
GeoMaster, LLC	GeoExcel	Open Loop	CA009, 012, 015
GeoMaster, LLC	GeoExcel	Open Loop	EC Models CS 018, 024, 030, 036, 042, 048, 060, 070
GeoMaster, LLC	GeoExcel	Open Loop	EC Models VT, HZ, CF 007, 009, 012, 015, 018

Organization Name	Model Name	Product Type	Model Number
GeoMaster, LLC	GeoExcel	Open Loop	EC Models VT, HZ, CF 024, 030, 036, 042, 048, 051, 060, 061, 070
GeoMaster, LLC	GeoExcel	Open Loop	EM007,009,018,024,028,031,036,042,048,060,070,072
GeoMaster, LLC	GeoExcel	Open Loop	EM Models VT, HZ, CF 007, 009, 018, 024, 028, 031
GeoMaster, LLC	GeoExcel	Open Loop	EM Models VT, HZ, CF 036, 041, 042, 048, 051, 060, 061, 070
GeoMaster, LLC	GeoExcel	Open Loop	EV Models CS 024, 030, 036, 042, 048, 060, 070
Heat Controller Inc.		Closed Loop	HRV/HRH030B1
Heat Controller Inc.		Closed Loop	HRV/HRH036B1
Heat Controller Inc.		Closed Loop	HRV/HRH042B1
Heat Controller Inc.		Closed Loop	HRV/HRH048B1
Heat Controller Inc.		Closed Loop	HSS018
Heat Controller Inc.		Closed Loop	HSS024
Heat Controller Inc.		Closed Loop	HSS030
Heat Controller Inc.		Closed Loop	HSS036
Heat Controller Inc.		Closed Loop	HSS042
Heat Controller Inc.		Closed Loop	HSS048
Heat Controller Inc.		Closed Loop	HSS060
Heat Controller Inc.		Closed Loop	HTD024 Full Load
Heat Controller Inc.		Closed Loop	HTD024 Part Load
Heat Controller Inc.		Closed Loop	HTD036 Full Load
Heat Controller Inc.		Closed Loop	HTD036 Part Load
Heat Controller Inc.		Closed Loop	HTD048 Full Load
Heat Controller Inc.		Closed Loop	HTD048 Part Load
Heat Controller Inc.		Closed Loop	HTD060 Full Load
Heat Controller Inc.		Closed Loop	HTD060 Part Load
Heat Controller Inc.		Closed Loop	HTD070 Full Load
Heat Controller Inc.		Closed Loop	HTD070 Part Load
Heat Controller Inc.		Closed Loop	HTS024 Full Load
Heat Controller Inc.		Closed Loop	HTS024 Part Load
Heat Controller Inc.		Closed Loop	HTS036 Full Load
Heat Controller Inc.		Closed Loop	HTS036 Part Load
Heat Controller Inc.		Closed Loop	HTS048 Full Load
Heat Controller Inc.		Closed Loop	HTS048 Part Load
Heat Controller Inc.		Closed Loop	HTS060 Full Load
Heat Controller Inc.		Closed Loop	HTS060 Part Load
Heat Controller Inc.		Closed Loop	HTV024 Full Load

Organization Name	Model Name	Product Type	Model Number
Heat Controller Inc.		Closed Loop	HTV024 Part Load
Heat Controller Inc.		Closed Loop	HTV036 Full Load
Heat Controller Inc.		Closed Loop	HTV036 Part Load
Heat Controller Inc.		Closed Loop	HTV048 Full Load
Heat Controller Inc.		Closed Loop	HTV048 Part Load
Heat Controller Inc.		Closed Loop	HTV060 Full Load
Heat Controller Inc.		Closed Loop	HTV060 Part Load
Heat Controller Inc.		Closed Loop	HTV070 Full Load
Heat Controller Inc.		Closed Loop	HTV070 Part Load
Heat Controller Inc.		Open Loop	HRV/HRH019B1
Heat Controller Inc.		Open Loop	HRV/HRH024B1
Heat Controller Inc.		Open Loop	HRV/HRH030B1
Heat Controller Inc.		Open Loop	HRV/HRH036B1
Heat Controller Inc.		Open Loop	HRV/HRH042B1
Heat Controller Inc.		Open Loop	HRV/HRH048B1
Heat Controller Inc.		Open Loop	HRV/HRH060B1
Heat Controller Inc.		Open Loop	HRV/HRH070B1
Heat Controller Inc.		Open Loop	HSS018
Heat Controller Inc.		Open Loop	HSS024
Heat Controller Inc.		Open Loop	HSS030
Heat Controller Inc.		Open Loop	HSS036
Heat Controller Inc.		Open Loop	HSS042
Heat Controller Inc.		Open Loop	HSS048
Heat Controller Inc.		Open Loop	HSS060
Heat Controller Inc.		Open Loop	HTD024 Full Load
Heat Controller Inc.		Open Loop	HTD024 Part Load
Heat Controller Inc.		Open Loop	HTD036 Full Load
Heat Controller Inc.		Open Loop	HTD036 Part Load
Heat Controller Inc.		Open Loop	HTD048 Full Load
Heat Controller Inc.		Open Loop	HTD048 Part Load
Heat Controller Inc.		Open Loop	HTD060 Full Load
Heat Controller Inc.		Open Loop	HTD060 Part Load
Heat Controller Inc.		Open Loop	HTD070 Full Load
Heat Controller Inc.		Open Loop	HTD070 Part Load
Heat Controller Inc.		Open Loop	HTS024 Full Load
Heat Controller Inc.		Open Loop	HTS024 Part Load

Organization Name	Model Name	Product Type	Model Number
Heat Controller Inc.		Open Loop	HTS036 Full Load
Heat Controller Inc.		Open Loop	HTS036 Part Load
Heat Controller Inc.		Open Loop	HTS048 Full Load
Heat Controller Inc.		Open Loop	HTS048 Part Load
Heat Controller Inc.		Open Loop	HTS060 Full Load
Heat Controller Inc.		Open Loop	HTS060 Part Load
Heat Controller Inc.		Open Loop	HTV024 Full Load
Heat Controller Inc.		Open Loop	HTV024 Part Load
Heat Controller Inc.		Open Loop	HTV036 Full Load
Heat Controller Inc.		Open Loop	HTV036 Part Load
Heat Controller Inc.		Open Loop	HTV048 Full Load
Heat Controller Inc.		Open Loop	HTV048 Part Load
Heat Controller Inc.		Open Loop	HTV060 Full Load
Heat Controller Inc.		Open Loop	HTV060 Part Load
Heat Controller Inc.		Open Loop	HTV070 Full Load
Heat Controller Inc.		Open Loop	HTV070 Part Load
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTHE30 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTHE51 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTHE60 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE30 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE40 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE51 (P)
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE60
Northern Heat Pump Inc.	XTERRA	Closed Loop	RTVE60 (P)
Trane and American Standard Heating and Air Conditioning	Commercial High Efficiency	Closed Loop with integrated WH	WPHF
Trane and American Standard Heating and Air Conditioning	Commercial High Efficiency	Closed Loop with integrated WH	WPVJ
Trane and American Standard Heating and Air Conditioning	EXHE	Closed Loop	All models All models EXHE018 to EXHE070
Trane and American Standard Heating and Air Conditioning	EXHE	Open Loop	All models EXHE018 to EXHE070
Trane and American Standard Heating and Air Conditioning	EXVE	Closed Loop	All models All models EXVE018 to EXVE070
Trane and American Standard Heating and Air Conditioning	EXVE	Open Loop	All models All models EXVE018 to EXVE070
Trane and American Standard Heating and Air Conditioning	GEHE	Closed Loop	GEHE072

Organization Name	Model Name	Product Type	Model Number
Trane and American Standard Heating and Air Conditioning	GEHE	Closed Loop	GEHE090
Trane and American Standard Heating and Air Conditioning	GEHE	Closed Loop	GEHE150
Trane and American Standard Heating and Air Conditioning	GEHE	Closed Loop	GEHE180
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE072
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE090
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE120
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE150
Trane and American Standard Heating and Air Conditioning	GEHE	Open Loop	GEHE180
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE072
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE090
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE120
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE150
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE180
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE240
Trane and American Standard Heating and Air Conditioning	GEVE	Closed Loop	GEVE300
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE072
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE090
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE120
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE150
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE180

Organization Name	Model Name	Product Type	Model Number
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE240
Trane and American Standard Heating and Air Conditioning	GEVE	Open Loop	GEVE300
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ030
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ036
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ042
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ048
Trane and American Standard Heating and Air Conditioning	WPVJ	Closed Loop	WPVJ060
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_026
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_038
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_049
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_064
WaterFurnace International, Incorporated	Envision	Closed Loop	ND_072
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_022
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_030
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_036
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_042
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_048
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_060
WaterFurnace International, Incorporated	Envision	Closed Loop	NS_070
WaterFurnace International, Incorporated	Envision	Open Loop	ND_026

Organization Name	Model Name	Product Type	Model Number
WaterFurnace International, Incorporated	Envision	Open Loop	ND_038
WaterFurnace International, Incorporated	Envision	Open Loop	ND_049
WaterFurnace International, Incorporated	Envision	Open Loop	ND_064
WaterFurnace International, Incorporated	Envision	Open Loop	NS_022
WaterFurnace International, Incorporated	Envision	Open Loop	NS_030
WaterFurnace International, Incorporated	Envision	Open Loop	NS_036
WaterFurnace International, Incorporated	Envision	Open Loop	NS_042
WaterFurnace International, Incorporated	Envision	Open Loop	NS_048
WaterFurnace International, Incorporated	Envision	Open Loop	NS_060
WaterFurnace International, Incorporated	Envision	Open Loop	NS_070
WaterFurnace International, Incorporated	Envision Console	Closed Loop	NC_09
WaterFurnace International, Incorporated	Envision Console	Closed Loop	NC_12
WaterFurnace International, Incorporated	Envision Console	Closed Loop	NC_15
WaterFurnace International, Incorporated	Envision Console	Open Loop	NC_12
WaterFurnace International, Incorporated	Envision Console	Open Loop	NC_15
WaterFurnace International, Incorporated	Envision Console	Open Loop	NC_18
WaterFurnace International, Incorporated	E Series	Closed Loop	E024
WaterFurnace International, Incorporated	E Series	Closed Loop	E030
WaterFurnace International, Incorporated	E Series	Closed Loop	E035
WaterFurnace International, Incorporated	E Series	Closed Loop	E036 Dual Capacity

Organization Name	Model Name	Product Type	Model Number
WaterFurnace International, Incorporated	E Series	Closed Loop	E040
WaterFurnace International, Incorporated	E Series	Closed Loop	E047
WaterFurnace International, Incorporated	E Series	Closed Loop	E048 Dual Capacity
WaterFurnace International, Incorporated	E Series	Closed Loop	E058
WaterFurnace International, Incorporated	E Series	Closed Loop	E060 Dual Capacity
WaterFurnace International, Incorporated	E Series	Closed Loop	E066
WaterFurnace International, Incorporated	E Series	Closed Loop	E072 Dual Capacity
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES024
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES030
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES036 Dual Capacity
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES048 Dual Capacity
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES060
WaterFurnace International, Incorporated	ES Series	Closed Loop	ES072 Dual Capacity
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ024
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ030
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ035
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ036
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ040
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ047
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ048 Dual Capacity

Organization Name	Model Name	Product Type	Model Number
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ058
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ060 Dual Capacity
WaterFurnace International, Incorporated	EZ Series	Closed Loop	EZ072 Dual Capacity
WaterFurnace International, Incorporated	Premier	Closed Loop	P010
WaterFurnace International, Incorporated	Premier	Closed Loop	P019
WaterFurnace International, Incorporated	Premier	Closed Loop	P022
WaterFurnace International, Incorporated	Premier	Closed Loop	P028
WaterFurnace International, Incorporated	Premier	Closed Loop	P034
WaterFurnace International, Incorporated	Premier	Closed Loop	P040
WaterFurnace International, Incorporated	Premier	Closed Loop	P046
WaterFurnace International, Incorporated	Premier	Closed Loop	P056
WaterFurnace International, Incorporated	Premier	Closed Loop	P066
WaterFurnace International, Incorporated	Premier	Closed Loop	P013
WaterFurnace International, Incorporated	Synergy	Open Loop	RTV046*1
WaterFurnace International, Incorporated	Synergy	Open Loop	RTV056*1
WaterFurnace International, Incorporated	Synergy	Open Loop	RTV066*1
WaterFurnace International, Incorporated	Synergy3	Closed Loop	RTV046
WaterFurnace International, Incorporated	Synergy3	Closed Loop	RTV056
WaterFurnace International, Incorporated	Synergy3	Closed Loop	RTV066
WaterFurnace International, Incorporated	Synergy 3D	Closed Loop	SDV038

Organization Name	Model Name	Product Type	Model Number
WaterFurnace International, Incorporated	Synergy 3D	Closed Loop	SDV049
WaterFurnace International, Incorporated	Synergy 3D	Closed Loop	SDV064
WaterFurnace International, Incorporated	Synergy 3D	Closed Loop	SDV072
WaterFurnace International, Incorporated	Synergy 3D	Open Loop	SDV038
WaterFurnace International, Incorporated	Synergy 3D	Open Loop	SDV049
WaterFurnace International, Incorporated	Synergy 3D	Open Loop	SDV064
WaterFurnace International, Incorporated	Synergy 3D	Open Loop	SDV072